

2080-LC50-STARTERPACK

Indhold	Katalog nr.
Micro850 Controller	2080-LC50-24QBB
Plug-In Modules	2080-IF2
Ethernet Cable	1 meter
USB Cable	1 meter
Micro830 Simulation Board	Input Simulator (7 digital inputs & 1 analog input)
Micro800 Power Supply	2080-PS120-240VAC
PanelView 800 HMI	2711R-T4T
CCW DVD	Installation DVD for CCW
Install manuals	Manuals for hardware included in the box
Getting Started Guide	Included in the box with the following information <ul style="list-style-type: none">- Setting up the products- Where to find the reference information



Now with PV800

kr. 3.120,-

1769-STRT11

Indhold	Stk	Katalog nr.
L16ER Controller	1	1769-L16ER-BB1B
HMI PVP7, Size 6",	1	2711P-T7C21D8S
USB Cable	1	1 meter
Ethernet Cable	1	1 meter
RSLogix 5K Lite S/W	1	9324-RLD250ENE
FT View ME S/W	1	9701-VWSTMENE
DVD with Product selection & Documentation	1	



kr. 10.850,-

440C-CR30-STARTERPACK1

Indhold	Stk.	Katalog nr.
E-Stop Assembled Station	1	800F-1YMQ3V
		440N-Z21SS3PA
		2080-PS120-240VAC
SensaGuard LiteLatch	1	700-HN123
120/240VAC to 24VDC Power Supply	1	700-HPS2Z24
Mini 8-Pin Screw Terminal Socket,	2	889D-F4AC-2
Safety Control Relay, 700-HP	2	2080-IQ4OB4
DC Micro (M12) PVC Cable	1	440C-CR30-22BBB
4-ch Digital Input/Output	1	598-PP1511
CR30 configurable safety relay	1	1 meter



kr. 3.382,-

2080-LC50-STARTERPACKL

Indhold	Katalog nr.
Micro850 Controller	2080-LC50-24QBB
Plug-In Modules	2080-IF2
USB Cable	1 meter
Micro830 Simulation Board	Input Simulator (7 digital inputs & 1 analog input)
Micro800 Power Supply	2080-PS120-240VAC
CCW DVD	Installation DVD for CCW
Install manuals	Manuals for hardware included in the box
Getting Started Guide	Included in the box with the following information <ul style="list-style-type: none">- Setting up the products- Where to find the reference information



kr. 1.980,-